

EcoSmart Shades - Clutch Driven Roller Shade Ballstop Installation Guide

After you've installed your shade, you must then set the limits using ball stops. The ball stops must be clamped onto the chain if you have a metal chain, or simply snapped into place if you have plastic chain. Here's a simple guide that shows you how to properly set the limits on your roller shade!

Tools required: Needle nose pliers

To set the upper limit, start by rolling the shade **up** to the desired limit.

Grab the first bead of chain just outside of the clutch.

Pull the chain down while holding that bead and attach the stop ball 2 beads above the one you are holding. If your shade has metal chain, clamp the stop ball to the chain using needle nose pliers.



To set the lower limit, start by rolling the shade **down** to the desired limit. Make sure to leave a small gap between the window sill and the fabric to prevent the shade from buckling.

Repeat the same process of grabbing the first bead of chain just outside the clutch.

Attach the stop ball 2 beads above the one you are holding.

